







ASSEMBLY INSTRUCTION

Ax1 	Gx1 
Bx1 	Hx1 
Cx1 	Ix4  M6*18mm
Dx1 	Jx2  M6*25mm
Ex1 	Kx2  M6*45mm
Fx1 	Lx1 

